



Assembly Instructions for Headboard Only

Thank you for purchasing your heirloom quality furniture from Sisters Log Furniture & Home Decor. Should you have any questions or need to contact sales or support, please do not hesitate to contact our store at 541.549.8191 or via E-Mail info@sisterslogfurniture.com

Tools Needed: 1/2" Wrench/Socket, 31/64" Drill Bit (1/2" Drill Bit is an OK substitute), Hammer

Before beginning assembly, please take a few moments to carefully read the instructions, familiarize yourself with the components and understand each step of the process. Likewise, please ensure that the hardware package contains the items as described below.

Parts List: (1) Headboard

Hardware List: (4) 2 1/2" Lag Bolts and Washers, (4) Lag Shield Inserts

Assembly Instructions:

Step 1. Layout parts in large well-lit area. Please note: There is no "front" or "back" to the headboard. Choose the side that you would like to face toward the bed.

Step 2. Line up existing bed frame (Hollywood frame) to the bed posts. Mark on posts where lag bolts will be needed (2 on each side).

Step 3. Drill 31/64" holes into marked spots on posts.

Step 4. Insert a lag shield insert into each of the 4 drilled holes of the headboard. Using a hammer, tap each shield until flush with the surface of the log. Be careful not to mar the wood.

Step 5. Stand headboard with the holes containing the lag shield inserts facing towards the metal frame.

Step 6. Place one washer onto each of the 4 lag bolts.

Step 7. Insert a lag bolt with washer through the slot on the metal mounting flange of the bed frame, screwing it into the corresponding hole on the headboard, tightening about 3/4 of the way until all 4 lag bolts are attached.

Step 8. Tighten all lag bolts fully at this time ensuring metal frame is flush & square with the headboard.

PLEASE NOTE: If you purchased your item "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. If the products intended use is outside, please use an exterior rated finish to also protect from weather damage. See use and care instructions for further information. Failure to adequately protect item by application and as needed, re-application of a final finish may void warranty.