



Assembly Instructions for Pub Table

Thank you for purchasing your heirloom quality furniture from Sisters Log Furniture & Home Decor. Should you have any questions or need to contact sales or support, please do not hesitate to contact our store at 541.549.8191 or via E-Mail info@sisterslogfurniture.com

Tools Needed: 1/2" Wrench/Socket, Phillips or Square Screw Driver

Before beginning assembly, please take a few moments to carefully read the instructions, familiarize yourself with the components and understand each step of the process. Likewise, please ensure that the hardware package contains the items as described below.

Parts List: (1) Table Top Assembly, (1) Pedestal Post Assembly, (4) Wooden Legs, (4) Top Braces

Hardware List: (16) 5/16" Nuts, (16) 5/16" Washers, (8) Phillips/Square Drive Screws, (4) Leg

Levelers *Assembly Instructions:*

Step 1. Remove components from shipping boxes. You may lay the cardboard on the floor to prevent marring of finish.

Step 2. Place pedestal post upright on floor. (hole locations are the same; either end up works fine!)

Step 3. Attach 4 wooden legs to the post using the 5/16" washers and nuts.

Step 4. Screw leg levelers into each leg. Ensure they are completely seated.

Step 5. Carefully turn pedestal post over so that the post is upright with legs resting on floor.

Step 6. Attach the four top braces to the pedestal post using 5/16" washers and nuts, ensuring the braces are as flush with the top of the post as possible.

Step 7. Gently place the table top face down on a clean, non-marring surface being careful not to scratch or dent it.

Step 8. Turn pedestal post over, carefully placing it on the table.

Step 9. Center the pedestal post on the 1" x 6" cross member attached to the table top.

Step 10. Using the 3" screws, secure the top braces to the cross member, making certain that the braces are flush against the table cross member.

Step 11. With the assistance of another person, turn the table over. Adjust the four leg levelers until satisfied.

PLEASE NOTE: If you purchased your item "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. If the products intended use is outside, please use an exterior rated finish to also protect from weather damage. See use and care instructions for further information. Failure to adequately protect item by application and as needed, re-application of a final finish may void warranty.